

Installation Instruction

Linear Pendant Luminaire

ELECTRICAL SHOCK HAZARD


WARNING

Disconnect the Electrical supply at the service panel (fuse or circuit breaker) before installation. Failure to do so could result in serious injury.

Only qualified electricians should install this luminaire and must follow the applicable local Electrical Code Part 1 or the NEC, and any local codes and ordinances. Ensure that all necessary proper tools and materials to complete the installation are available before attempting to install this luminaire.


Read all instructions prior to installing this product.

IMPORTANT CALCULATION FOR CONTINUOUS RATING



Type	Length
2FT	23.62"
3FT	35.43"
4FT	47.24"
5FT	59.06"
6FT	70.87"
7FT	82.68"
8FT	94.49"

Ceiling



ST

PO


AI

Aircraft c



Susp

CONTINUOUS INSTALLATION FOR DIRECT AND IN


Remove lens by tool




Loose screws and
remove gear tray



Insert Joint plate to housing





Lock plate in position




Inse




NON-POWER FEED




POWER FEED




GRID NON-P





Drop Ceiling System (Non Feed)



Drop Ceiling



Included Accessories in the Package

1	2	3	4	5
				
AL Linear light joint lock holder	Suspension coupler/ Canopy holder	Canopy with power access, 5"	Grid ceiling mounting bracket	Joint plates for ZNTH Narrow and Wide
1×1	1×2	1×1	1×2	

8	9	10
		
suspension holder	suspension cable	Allen Key
1×2	1×2	1×1