

# Installation Instruction

## Linear Wall Luminaire

---

**ELECTRICAL SHOCK HAZARD**

### WARNING


Disconnect the Electrical supply at the service panel (fuse or circuit breaker) before installation. Failure to do so could result in serious injury.

Only qualified electricians should install this luminaire and must follow the applicable National Electrical Code Part 1 or the NEC, and any local codes and ordinances. Proper tools and materials to complete the installation are available. Do not attempt to install this luminaire.

Read all instructions prior to installing this product.

**IMPORTANT CALCULATION FOR CONTINUOUS RATING**

**Pull power feed wires through center hole of cover plate to switch box**



**CONNECT WI**


**BLACK**

**WHITE**

**GREEN**

**PURPLE**

**PINK**



**Type**

2FT

3FT

4FT

5FT

6FT

7FT



8FT




**WARNING:** ENSURE THAT MOUNTING LOCATION AND METHOD IS SUFFICIENT TO SUPPORT THE WEIGHT OF THE PRODUCT.

# CONTINUOUS INSATLLATION FOR DIRECT – DO M floor – Must be connected after hanging on the wall


Remove lens by tool




Loose screws  
remove gear t



Loose 2 screws and  
remove End cap



Insert Joint plate to housing




Insert Joint lock holder to brackets



Fix lock holder to

Included Accessories in the Package

1	2	3	4	5
				
<p>AL linear light joint lock holder</p>	<p>Joint plates for ZNTH60, Narrow and Wide</p>	<p>Lens removal tool</p>	<p>ZNTH60 W housing mounting bracket unit</p>	<p>Allen key</p>
<p>1×1</p>	<p>1×2</p>	<p>1×1</p>	<p>1×2</p>	