

Installation Instruction

Linear Wall Luminaire

ELECTRICAL SHOCK HAZARD

WARNING


Disconnect the Electrical supply at the service panel (fuse or circuit breaker) before installation. Failure to do so could result in serious injury.

Only qualified electricians should install this luminaire and must follow the applicable local Electrical Code Part 1 or the NEC, and any local codes and ordinances. Ensure that all necessary proper tools and materials to complete the installation are available before attempting to install this luminaire.

Read all instructions prior to installing this product.

IMPORTANT CALCULATION FOR CONTINUOUS RATING

Pull power feed wires through center hole of cover plate to switch box



CONNECT WI


BLACK

WHITE

GREEN

PURPLE

PINK



Type

2FT

3FT

4FT

5FT

6FT

7FT


8FT




WARNING: ENSURE THAT MOUNTING LOCATION AND METHOD IS SUFFICIENT TO SUPPORT THE WEIGHT OF THE PRODUCT.

CONTINUOUS INSATLLATION FOR DIRECT – DO M floor – Must be connected after hanging on the wall


Remove lens by tool




Loose screws
remove gear t



Loose 2 screws and
remove End cap




Insert Joint plate to housing






Loc

Insert Joint lock holder to brackets



Fix lock holder to

Included Accessories in the Package

1	2	3	4	5
				
AL linear light joint lock holder	Joint plates for ZNTH60, Narrow and Wide	Lens removal tool	ZNTH60 W housing mounting bracket unit	Allen key
1×1	1×2	1×1	1×2	