

Installation Instruction

Linear Wall Luminaire

ELECTRICAL SHOCK HAZARD

WARNING


Disconnect the Electrical supply at the service panel (fuse or circuit breaker) before installation. Failure to do so could result in serious injury.

Only qualified electricians should install this luminaire and must follow the applicable National Electrical Code Part 1 or the NEC, and any local codes and ordinances. Proper tools and materials to complete the installation are available. Do not attempt to install this luminaire.

Read all instructions prior to installing this product.

IMPORTANT CALCULATION FOR CONTINUOUS RATING

Pull power feed wires through center hole of cover plate to switch box



CONNECT WI


BLACK

WHITE

GREEN

PURPLE

PINK



Type

2FT

3FT

4FT

5FT

6FT

7FT


8FT





WARNING: ENSURE THAT MOUNTING LOCATION AND METHOD IS SUFFICIENT TO SUPPORT THE WEIGHT OF THE PRODUCT.

CONTINUOUS INSATLLATION FOR DIRECT – DO M floor – Must be connected after hanging on the wa

Remove lens by tool





Loose screws
remove gear t



Loose 2 screws and
remove End cap

Insert Joint plate to housing

Loc




Insert Joint lock holder to brackets

Fix lock holder to



Included Accessories in the Package

1	2	3	4	5
				
<p>AL linear light joint lock holder</p>	<p>Joint plates for ZNTH60, Narrow and Wide</p>	<p>Lens removal tool</p>	<p>ZNTH60 W housing mounting bracket unit</p>	<p>Allen key</p>
<p>1×1</p>	<p>1×2</p>	<p>1×1</p>	<p>1×2</p>	